

## 2-Line installation


One line to cylinder, one line to the reservoir. for intermittent operation only.



Spool in Neutrol Position: Oil recirculates internally.




Oil is routed through work port to raised the cylinder.




Spool in Lower Position: Oil flows from the cylinder through the relief valve to return to tank.

## 3-Line installation



Note: Three-line installation is always recommended whenever possible. Simply install the sleeve supplied in the inlet port and connect the optional return line to tank. This will maintain a lower operating temperature. We also recommend the use of a return line filter.

Two-line systems are for intermittent operation only.



3 Line Wet Line Kit for Dump Application