



If truck is 1998 or older you may need to reuse original side channels.
NOTE: Remove bolts and apply heat to soften adhesive between core and brackets to remove.